



# XL RUBBER FLOOR CLEANER

## Tech Data Sheet



**XL Rubber Floor Cleaner** is a Rubber Floor Cleaner / Maintainer that can be mopped, sponged or auto scrubbed.

### WHERE TO USE

**XL Rubber Floor Cleaner** is specially formulated for use on Rubber Floors.

### APPLICATION

#### Initial Cleaning

Sweep the floor first using a dust mop or hard surface vacuum. Apply diluted solution of **XL Rubber Floor Cleaner** to new floor with mop or pump sprayer, allow to dwell for 5-15 minutes (Do Not allow solution to dry), scrub area as recommend by manufacturer, remove slurry with extraction machine or wet vacuum Rinse floor thoroughly with fresh water.

**ROUTINE MAINTENANCE:** Use **XL Rubber Floor Cleaner** for routine mopping or auto scrubbing on soiled areas as needed.

**RESTORATIVE CLEANING:** **XL Rubber Floor Cleaner** may be used for very aggressive cleaning. Apply liberal amount of diluted solution to soiled area. Allow to dwell, then agitate solution with rotary floor machine or automatic scrubber. Remove slurry with extraction machine or wet vacuum. Rinse the floor thoroughly with fresh water.

### MIXING DIRECTIONS

**INITIAL/ROUTINE MAINTENANCE:** Use 2 (60ml) to 4(120ml) ounces per gallon (3.8lts) of cold water.

**RESTORATIVE CLEANING:** Use 4 (120ml) to 6 (170ml) ounces per gallon (3.8lts) of cold water.

### TECHNICAL SPECIFICATIONS

COLOR: ..... Clear  
FORM: ..... Liquid  
SCENT: ..... Mild  
pH: ..... 7.0  
FLASH POINT: ..... None  
FOAM: ..... None  
VISCOSITY: ..... Water Thin

STORAGE (Unopened): .... 1 Year @ R.T.  
BIODEGRADABLE: ..... Yes  
WEIGHT/GAL: ..... 8  
SHIPPING CLASS: ..... None  
PACKAGING: ..... 4x1 Gal. Case, 5 Gal. Pail  
TYPE: ..... Cleaner  
DILUTION: ..... 2 (60ml) - 6 (170ml) oz

FOR COMMERCIAL AND INDUSTRIAL USE ONLY

©2014, Cleaner Floors, Belmont, WA, 6104, AUS



Questions or Comments:  
**(08) 9277 7177**

[www.cleanerfloors.com.au](http://www.cleanerfloors.com.au)

Rev. 020912a